

# AUTOMATIC MODE

Interceptor  
Extension

Roll  
Angle

Interceptor  
Feedback

Pitch  
Indicator

Pitch  
Angle

Boat  
Speed

Turn  
Radius

Roll  
Level

Pitch  
Offset

MENU


AUTO

SERIES E


Press and hold:  
Auto Pitch & Roll  
Control on/off

Press: Auto Roll  
Control off/on



Roll Level



Pitch Offset



Save Pitch  
Offset



# OPERATOR'S QUICK GUIDE

# MANUAL MODE

**Interceptor Extension**

**Roll Angle**

**Interceptor Feedback**


**Pitch Indicator**

**Boat Speed**

**Pitch Angle**

**Steering Mode**

**Turn Radius**



**MENU**

**AUTO**

**Press and hold:**  
System on/off

**Press:**  
Enter Menu

**Steering Mode on/off**

**Roll Control**

**Pitch Control**

